

# **BREAK-AWAY UNITS**









# BREAK-AWAY UNITS BREAKSAFE



#### 4024 SA6000 BREAKSAFE UNIT

- TO SUIT 2 & 4 WHEEL BRAKE
- INCLUDING:
  - 1 OFF NP7 12V BATTERY
  - 1 OFF BREAKAWAY SWITCH c/w COIL CABLE
  - SET OF MOUNTING HARDWARE
  - INSTALLATION INSTRUCTION BOOK



#### 4068 SA6000XP BREAKSAFE UNIT

- TO SUIT 6 WHEEL BRAKE
- INCLUDING:
  - 1 OFF NP9 12V BATTERY
  - 1 OFF BREAKAWAY SWITCH c/w COIL CABLE
  - SET OF MOUNTING HARDWARE
  - INSTALLATION INSTRUCTION BOOK



# **BREAK-AWAY UNITS**

## BREAKSAFE

	PART NUMBER	DESCRIPTION
REMOTE BRITTERI MONTO!	SA5000RM	5000 REMOTE MONITORS
MAINTENANCE - FREE RECHARGEAUE EATTEN NP7 - 12 12 VOLT 7.0 AH www.relectronics.com.au Phone og 8261 3400 Pax 08 8261 3400	ВАТ	REPLACEMENT BREAKSAFE BATTERY 7 A/H - TO SUIT SA6000
MAINTENANCE - FREE RECHARGEABLE BATTEN NP9 - 12 12 VOLT 9.0 AH www.velectronics.com au Phone: 68 6261 3500 Fax: 08 8261 3400	ВАТХР	REPLACEMENT BREAKSAFE BATTERY 9 A/H - TO SUIT SA6000XP
CAUTION: TO AW INDOM THE	SA0172W	REPLACEMENT COIL CABLE & PIN
SAUTON	SA0172	REPLACEMENT BREAKAWAY SWITCH c/w COIL CABLE



# StaySAFE

### **ELECTRIC BREAK-AWAY SYSTEM**



#### **SA7000 StaySAFE UNIT**

- TO SUIT 2000 4499KG ON 2, 4 & 6
   WHEEL BRAKE
- PASSED TEST IN AUSTRALIA TO ADR38/04 SPECIFICATIONS
- COMPLIES WITH ADR38/04 AUSTRALIA WIDE (REMOTE MONITOR FOR NSW)
- INCLUDING:
  - A StaySAFE CONTROL UNIT WITH HEAVY DUTY 12V BATTERY (1 OFF)
  - B StaySAFE REMOTE BATTERY LEVEL MONITOR (1 OFF)
  - C StaySAFE 240V to 12V BATTERY CHARGER (1 OFF)
  - D StaySAFE BREAKAWAY SWITCH c/w LANYARD & CLIP (1 OFF)
  - COMPREHENSIVE INSTRUCTION BOOK (1 OFF)
- SPARE PARTS AVAILALE